

## **MUSTIQUE DIGITAL TELEVISION RE-TUNE STEPS: SILVER 'Iote-x' BOX**



Using the Remote Control, follow these steps to re-tune your TV BOX

- 1. Press "Menu", highlight "Digital TV" and Press OK**
- 2. Highlight "Channel Manager" and Press OK**
- 3. Highlight "Delete All" and Press OK**
- 4. Enter the password (Default=0000)**
- 5. Highlight "All TV Channels" and Press OK**
- 6. Highlight "Yes" and Press OK**
- 7. Highlight "All Radio Channels" and Press OK**
- 8. Highlight "Yes" and Press OK**
- 9. Press "Exit" twice**
- 10. Highlight Installation and Press OK**
- 11. Enter the password (Default=0000)**
- 12. Highlight "Manual Search" and Press OK**
- 13. Set Freq(KHz) to 525000 using the numeric keys**
- 14. Set Bandwidth to 8M using the left & right keys**
- 15. Press OK and wait for searching to complete**
- 16. Repeat Steps 12 through 15 for Freq(KHz) 537000**
- 17. Repeat Steps 12 through 15 for Freq(KHz) 549000**
- 18. Repeat Steps 12 through 15 for Freq(KHz) 561000**
- 19. Press Exit 3 times to exit the Menu**